

galassi & ortolani s.p.a.

valvole speciali per l'industria

Via Ghirlandaio, 2/4
20096 Pioltello -MI- (Italy)

Tel. ++39-02-92103459
Tel. ++39-02-92103801/02
Fax ++39-02-92103804

<http://www.galassiortolani.com>
E-mail: info@galassiortolani.com

Instruction Manual

Butterfly valve model GS.33-33W

Hand operated butterfly valve.

The valves of this type model GS.33-33W are useful for regulating or cutting off the flow of alkaline, acid or corrosive solutions.

To maintain a high, level of efficiency it is advisable to change the rubber coupling and the butterfly when required.

To replace the coupling and butterfly:

1. Remove the pin (part.2) and slide out the control lever (part.1).
2. Remove the bolts, washers and nuts (part.11-12-13) and open the upper part of the valve body (part.3) taking it off the lower (part.4).
3. With the butterfly disk in a open position, press down the coupling and slide out the butterfly.

To re-assemble:

1. Slide the longer shaft of the butterfly into the coupling hole, press down the coupling and insert the shorter end.
2. Insert the butterfly with the coupling into the valve body seats, bolt and insert the control level.

N.B. All part numbers will be found in our technical and parts catalogues.